

Wire Wrap a Grooved Stone

The process is very simple. Use the Club's grooving to make a slit around the edge of your cabochon. Keep the wheel wet with the sponge. You will want the wire to show around the edge of the stone so the groove should be slightly less deep than the width of your wire.

You can make the cabochon either before or after you cut the groove.

Use the Alan wrench to loosen the head and adjust the height. You will want the groove in the center your stone. The table top is flexible so Do Not press downward when cutting or the cut will not be in the center.

